



































Getting Started

1-2-3-4 Program Options

you do not h

here to displa

ues in the Tag

ve you enteri


e saved auto



own callsign



here to select

or select Prog

of page.







(1) Tags (Callsign, Name, ...)



Click [here](#) to display the Tags window.

Enter values in the Tags window, these values are used in macros (shortcuts which save you entering the same text every time you have a QSO). The values are saved automatically.


Put **your own callsign** in the **About Me: Callsign** field.

(2) Soundcard



Click [here](#) to select your soundcard or press F8 to display the *Program Options* (or select *Program Options* from the *Tools* menu) and select the *Soundcard* page.

(3) Radio Interface (HRD)



(3) Radio Interface (HRD)



Click [here](#) to set up an optional connection between DM780 and HRD, this is used for radio control such as changing frequency or filters.

In DM780 open the *Radio* display (select *Radio* from the *View* menu),

Press  *Configure* (the right-most button on the toolbar),

Read the help text, this contains everything you need to know!

When you have finished close the Radio display by clicking on the X at the top-right corner.

(4) PTT



Click [here](#) to select a PTT option or press F8 to display the *Program Options* (or select *Program Options* from the *Tools* menu) and select the *PTT* page.

